



**INSTRUCTION
MANUAL
440585-V0E-TLD**

We want you to know all about your new telephone, how to install it, the features it provides, and the services you can expect from its use. We have included this information in your Owner's Instruction Manual.

Features:

- * Tone/Pulse Switchable Dialing
- * Last Number Redial
- * Electronic Tone Ringer
- * Flash with PBX Compatibility
- * Receiver Volume Control
- * Lighted Dial
- * Tropicalized

TELEPHONE PART IDENTIFICATION



TELEPHONE FEATURES

TELEPHONE SET UP

1. Use the new line cord to connect the PHONE jack of your new telephone to the modular wall jack.
2. Place the unit on a flat table or mount it on a wall. To mount the unit on a wall, you must use the wall mount bracket supplied. You must also remove the tab below the handset receiver and turn it around.

PULSE AND TONE DIALING

1. If your telephone line accepts touch-tone dialing, set the **PULSE/TONE** switch to the Tone position. The switch is located on the right side of the telephone. The default position is tone dialing.
2. If your telephone line requires rotary (pulse) dialing, set the **PULSE/TONE** switch to the Pulse position.
3. If you are unsure which system you have, set the switch to the **PHONE** position. Lift the handset. When you get a dial tone, dial a telephone number. If the dial tone continues, move the switch to **PULSE**, and then dial the telephone number again.

RECEIVING A PHONE CALL

1. Be sure the **RINGER** switch is set to the desired position.
2. When the phone rings, lift the handset.

PLACING A PHONE CALL

1. Lift the handset and wait for a dial tone.
2. Dial the telephone number you wish to call.

REDIAL BUTTON

1. If the number you dialed is busy, or you want to call the last number dialed again, lift the handset , or press and release the hookswitch for a new dial tone.
2. Press **REDIAL**.
3. The last number called will automatically be redialed.

FLASH BUTTON

This telephone provides a line break signal for accessing PABX service or for convenient use of Call Waiting from your local telephone company. If you have Call Waiting service, you can alternate the Call Waiting function per the following instructions.

1. While having a conversation, another party calls and you hear a tone.
2. Press the **FLASH** button once and release. The first conversation is placed on hold and the second call can be answered.
3. Press **FLASH** button again and release. The first caller can be spoken to again and the second call is placed on hold.

HANDSET VOLUME CONTROL

Use the Handset **Volume** slide control located on the right side of the phone base to change volume control. This increased volume should allow persons with hearing impairments to carry on normal conversations by adjusting the receive volume to its proper level.

RINGER VOLUME

Use the **Ringer Volume** control located on the right side of the phone base to change ringer volume from low to high.

TROUBLESHOOTING

PHONE DOES NOT RING

1. Line cord is disconnected at telephone outlet or at telephone end.
2. Phone is **OFF HOOK**. Make certain the hookswitch is depressed when the handset is in the cradle.

NO DIAL TONE

Wire is disconnected at telephone jack or at wall jack. Test the telephone in a different wall jack. If it works, the first jack may be defective.

HAVE DIAL TONE BUT CANNOT DIAL OUT

Check if the PULSE/TONE switch is in the correct position.

REDIAL BUTTON DOES NOT FUNCTION

The telephone may have been momentarily disconnected from the telephone jack.

MAINTENANCE INFORMATION

Treat your telephone equipment with care for trouble-free performance. Avoid dropping the handset. Carefully place the handset on-hook after use.

Avoid putting near heating appliances and devices that generate electrical noise (for example, motors and florescent lamps).

Clean your telephone equipment with a damp cloth. Stains may be removed with a mild soap. Do not use liquid or aerosol detergents or cleaning agents.

Do not expose to direct sunlight or moisture